



PATENT

IN THE UNITED STATES PATENT AND TRADEMARK OFFICE

In re: Kendall, et al. Docket No.: IR-2795(EC)
Serial No.: 09/888,793 Filing Date: 6/25/2001
Examiner: Robert D. Harlan Art Unit: 1713
For: "Metathesis Polymerization Adhesives and Coatings"

HQ
Freddy
12/8/02

Nov. 22, 2002

Assistant Commissioner for Patents
Washington, DC 20231

DECLARATION PER 37 C.F.R. 1.131

Sir:

This is in response to the Office Action dated May 22, 2002. The undersigned Applicants declare the following:

As a below named inventor, we hereby declare that:

Our residence, post office address and citizenship are as stated below next to our names; and

we believe we are the original, first and joint inventors of the subject matter which is claimed and for which a patent is sought on the invention entitled, "Metathesis Polymerization Adhesives and Coatings" the specification of which was filed 6-25-01 in the United States Patent and Trademark Office.

Submitted as attached is objective evidence of invention by Applicants prior to the reference effective date, December 5, 2000 of Japanese Kokai Patent Application 336320 as attached photocopy pages of Notebooks and is evidence of actual reduction to practice, summarized as follows:

RECEIVED
DEC 02 2002
TC 1100

Pages 28 and 29 from Notebook No. 8148, evidencing that polymerization between rubber and metal with bonding was achieved using Grubb's catalyst and ENB monomer.

Pages 58 and 59 from Notebook No. 8060 showing that Grubbs catalyst coatings on EPDM substrate followed by coating of p-ENB resulted in a polymerized coating; and catalyst coatings on glass slides followed by spraying of ENB monomer resulted in a peelable solid coating film.

Page 57 from Notebook No. 8148 showing that monomer mixtures of ENB and TCHP polymerized with Grubb's catalyst.

Pages 50 and 51 of Notebook No. 8297 demonstrated contact metathesis adhesion between different polyolefin (LDPE) substrate bonded to itself with 5,5-bis(chloromethyl)-2-norbornene using Grubb's catalyst.

Pages 41 and 42 of Notebook No. 8327 demonstrated the bonding of polypropylene to itself using 5,6-bis(chloromethyl)-2-norbornene delivered from a 2-part cartridge.

Pages 66 and 67 of Notebook No. 8327 demonstrated bonding of polypropylene using ENB and Grubb's catalyst.

Pages 64 to 65 of Notebook No. 8363 demonstrated formulation as a two part adhesive of ENB, NBD, silica, and an elastomer (Europrene) provided a measured amount of bond strength in lap shear samples.

Pages 11, 12, 15, 22 and 23 of Notebook No. 8374 demonstrated formulation as a two part adhesive of norbornadiene, ENB, Blendex, Cab-o-sil and Zeeospheres provided a measured bond strength in lap shear polypropylene samples.

Pages 51 to 56, 59-60 and 89-90 of Notebook No. 8374 demonstrated 2-part adhesive formulations applied to bond polypropylene substrates.

We further declare that all statements made herein of our own knowledge are true and that all statements made on information and belief are believed to be true; and further that these statements were made with the knowledge that willful false statements and the like so made are punishable by fine or imprisonment, or both, under Section 1001 of Title 18 of the United States Code and that such willful false statements may jeopardize the validity of the application or any patent issued thereon.

Full name of first inventor: Jonathan L. Kendall
Inventor's Signature: 

Date: Nov. 22, 2002

Residence: Apex, North Carolina

Citizenship: United States of America

Post Office Address: 704 Nottinghill Walk
Apex, North Carolina 27502

Full name of second inventor:

Inventor's Signature:

Date: Nov. 22, 2002

Residence: Apex, North Carolina

Citizenship: United States of America


Post Office Address: 109 Lewey Brook Drive
Cary, North Carolina 27519

CERTIFICATE OF MAILING (37 CFR 1.8(A))

I hereby certify that this paper (along with any paper referred to as being attached or enclosed) is being deposited with the United States Postal Service on November 22, 2002 with sufficient postage as first class mail in an envelope addressed to the Assistant Commissioner of Patents, Washington, DC 20231.

Andrea M. Clark

Dat



Project No. 8148 TITLE _____

From Page No. _____


Rubber to Metal Bonding Using Monomer / Catalyst Mixture

Materials: ENB (CK8148-15-1); Grubbs's catalyst (Strem); EPDM (J. Taylor); Grit Blasted Metal Coupons (M. Righettini)

Procedure:

- 1) 0.0009g of catalyst (0.000001 moles) was weighed into a glass vial.
- 2) 2.8ml (2.5004g or 0.0208 moles) of ENB was quickly syringed into the glass vial and immediately stirred for a few seconds.
- 3) The monomer / catalyst mixture was then dropped onto the EPDM strip using a glass pipet. The metal coupon was finally placed over the treated EPDM surface and held in place until bonding occurred. A brown jar was placed over the bonded area. Monomer to catalyst molar ratio was 20,800:1.
- 4) Bonding procedure was as follows (pictured from above description):

Surface was sanded, acetone wiped and tape removed. The monomer / catalyst mixture was pipetted onto the surface. Not spread because polymerization starting.



Immediately, the acetone washed metal coupon was placed on the EPDM strip in treated area. Material came out the sides and polymerized during bonding. The coupon was held in place until had to move.

RECEIVED
DEC 02 2002
TC 1700

To Page No. 29

Witnessed & Understood by me,

S E Anthony

Date

[Signature]

Invented by

Recorded by *Chris Keck*

Date

[Signature]


From Page No. 28

5) 5 hrs after bonding, metal easily pulled apart from rubber. Nothing on metal. Rubber had a thin, elastic film stuck to it.

PART II

Steps 1-4 (pages 28) were repeated. However, this time the monomer/catalyst mixture was pipetted onto the metal sulfate and the EPDM quickly placed onto the metal sulfate. The results of the first experiment. 17 hrs after bonding, metal again easily pulled apart from the rubber. Like above, nothing on metal while rubber had a thin, elastic film stuck to it.

C.R.



To Page No. _____

Witnessed & Understood by me,



Date



Invented by

R c rded by

Chris Keck

Date



Project No. 8055
B k No. 8060 TITLE ESCA Samples

From Pag N 58

Purpose: To prepare samples for surface analysis on CMP technology.
Ed Tokas will be taking different samples to NJ w/ MASTo conduct ESCA analysis.

Instructions: from Ed Tokas

Printed By: Ed Tokas	Page: 1	RECEIVED OR PH
From: Ed Tokas (cc: Russ) To: Chris Keck, Russell Walls CC: Ken Caster, Steve Howe, Marlene Righettini, Lynn Yancy REGARDING: CMP Samples for Analysis Chris and Russ,		
Giving you a reminder that next week I will be going to conduct two separate surface analyses on CMP samples:		
1st Tuesday Marlene and I will go to NCSU to run a cross sectional analysis on R/R bonded samples (one freshly prepared and one aged sample).		
2nd On Wednesday I will be going to NJ w/ MASTo conduct ESCA analysis and will need the following samples:		
Labeled as Notebook Page	Sample	
✓ -1	EPDM (for all preps in this series use the 1/16 in. pads located in my office)	
✓ -2	EPDM w/ catalyst	
-3	EPDM w/ a thin layer of poly-ENB (thinnest of three samples)	
-4	EPDM w/ intermediate thickness of poly-ENB	
-5	EPDM w/ thick layer of poly-ENB	
-6 and -7	A free film of poly-ENB (prepared on glass and carefully removed)	
-8	A bulk polymerized poly-ENB (prepare in a cube)	
✓ -9	Metal coupon (the grit blasted Fe coupons we have been using)	
✓ -10	Metal w/ catalyst (the grit blasted Fe coupons we have been using)	
See me Monday AM to discuss.		
Thanks Ed		

Russell

Walls

~~RECEIVED~~

Procedure/Log

Time Comments

8:30 am ~~(1/15)~~) Discussion with Ed Tokas to make clear what is to be done.

Since the samples are to be sprayed, I was instructed to prepare most of the samples. Chris Keck was instructed to make the bulk polymerized poly-ENB in a small test tube.

- 1:00 pm Ed Tokas wanted to be present for first spraying. 0.75g of pyrrole catalyst was dissolved in 10ml methanol and swirled till dissolved.
- 1:10 pm Coated $\frac{1}{16}$ " 6×6 " EPDM with catalyst on two passes, dry, and mixed with acetone to clean first. two more passes for a total of 4 passes. Ed said it looked fine. Asked that we wait 30 minutes before applying monomer.

To Pag No. 59

Witness d & Understood by m ,

James B Deign

Date

~~RECEIVED~~

Invented by

Recorded by Russell Deign


Dat

~~RECEIVED~~

From Page No. 58

- | <u>Time</u> | <u>Comments</u> |
|-------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1:40 pm | Applied thin coat of poly-ENB by making two passes over the rubber surface. Allowed to dry in hood. Smell of monomer still present. 1 sample not yet catalyst stored. |
| 1:45 pm | <ul style="list-style-type: none"> Acetone wiped EPDM labelled as RW8060-58-1 with silver pen on back and placed in ziplock bag. Bag labelled and brown paper placed in front of surface to be tested so that it would not come in contact with plastic of bag. EPDM with just catalyst labelled as RW8060-58-2 and stored in ziplock bag just like RW8060-58-1. |
| 2:00 pm | <ul style="list-style-type: none"> Forgot to note that at 1:40 pm I also coated two small metal coupons (not grit blasted) with 2 mils catalyst. Stored and labelled as RW8060-58-10 and placed in ziplock bag. The unsprayed coupons just wiped with acetone stored and labelled as RW8060-58-9. Also at 1:40 pm I coated one minus glass slide with catalyst. |
| 2:20 pm | Sprayed glass coated slide with monomer (ENB). Solvation occurred to disrupt smoothness of catalyst evenly applied |

Monomer coating saturated and peeled catalyst holes are clear, while cut is purple.



Initial coating evenly placed on slide glass

- Subsequent spraying of monomer done to build thickness.
Razor blade at edge indicates peelable coating. Allowed to dry fully before storing and labelling as RW8060-58-6 and -7 in ziplock bag.
- 3:00 pm
- Made another catalyst solution 0.75 gm in 10 ml Me_2
 - We have been leaving the gloving on each sample so far. This means that we have coated it as well.
 - After wiping surface of RW8060-58-4 sample with acetone I attempted to weigh to help determine coating weight, but couldn't get accurate reading. The 6x6" with gloving is too large to weigh with draft shield in place and air currents in lab-5 are too great to get accurate weight. Veeco tester may be used to determine thickness.

To Page No. 60

Witnessed & Understood by me,

James B Deger

Date

~~[Signature]~~

Invented by

R corded by Russell Dalls

Date

~~[Signature]~~

TITLE _____

From Page No. _____
~~██████████~~

Catalyst Activity Study Using Tricyclohexylphosphine.

Materials: Tricyclohexylphosphine (TCHP, 97%, from Aesar); ENB (CK 8148-15-1); Grubbs's Catalyst (Boulder)

Procedure:

1) Polymerization with ENB and the Grubbs's catalyst is very fast.

TCHP was added to the catalyst in order to slow down the polymerization. Different amounts of TCHP was added to the catalyst and then the ENB syringed into the mixture. Time of polymerization was then recorded. Table of results shown below:

M/I Ratio	TCHP/I Ratio	ENB(ml)	I(gms)	TCHP(gms)	Polymerization Time
5,000:1	2:1	3.0	0.0037	0.0025	1 min.
5,000:1	5:1	3.0	0.0037	0.0063	2 min.
5,000:1	10:1	3.0	0.0037	0.0125	4 min.
5,000:1	Control	3.0	0.0037	—	13 sec.
10,000:1	2:1	3.0	0.0018	0.0013	1 min. 4 sec.
10,000:1	5:1	3.0	0.0018	0.0031	2 min. 15 sec.
10,000:1	10:1	3.0	0.0018	0.0063	4 min. 50 sec.
10,000:1	Control	3.0	0.0018	—	72 sec.

M = Monomer (ENB)

I = Initiator (Grubbs's Catalyst)

TCHP = Tricyclohexylphosphine

To Page No. _____

Witnessed & Understood by m ,

Date
~~██████████~~

Inv nt d by

Date


Recorded by Chris Keck

From Page No. 50

~~██████████~~

CMP of polyolefins with
5,6-bis(chloromethyl)-2-norbornene

Polypropylene and LDPE strips were



covered, as shown in the picture on the

left, with ~0.1mL each of 5,6-bis(chloro-
methyl)-2-norbornene. The area covered was 1 in² at the
end of a 6" x 1" strip. Two strips of each substrate

~~types~~ were treated. A solution of 10mg Grubbs' catalyst

in ~0.1mL 5,6-bis(chloromethyl)-2-norbornene was

prepared and quickly applied to one of each substrate
types such that the solution was divided evenly between

The two substrates. The catalyst solution was spread

evenly over the 1 in² end of the substrate. The

corresponding substrate without catalyst was inverted

and placed in contact with the ~~XK-~~ catalyst solution.

A 200g weight was placed on the top of the substrates

& the reaction was allowed to cure for 24h.

To Page No. 51

Witnessed & Understood by me,

Amy C. Burke

Date

~~██████████~~

Invented by

John Kendall

Date

~~██████████~~

Recorded by

John Kendall

From Page No. 50

After 24 h, the weight was removed from the samples & the bond strength was tested by hand.

When tested by shear: ← [] → The bond could not be broken by hand. When tested under Peel conditions ↑ [] ↓ After some

Slight initial effort, the samples peeled off with ease. That is, once a crack was formed it propagated at the adhesive-substrate interface with ease.

The adhesive was a hard plastic-like material.

To Page N .

Witnessed & Understood by m ,

Amy C. Burke

Date

[REDACTED]

Inv nt d by

Gather Kudall

Rec rded by

Gather Kudall


Date

[REDACTED]

From Page No. _____

Bonding of Polypropylene Using 5,6-bis(chloromethyl)-2-norbornene, $\text{WCl}_4(\text{O}-\text{O})_2$, + SnBr_4 delivered as a 2-part adhesive from a cartridge.

A solution of 136 mg (167 μmol) $\text{WCl}_4(\text{O}-\text{O})_2$ in 1g 5,6-bis(chloromethyl)-2-norbornene + 40mg polyENB (synthesized in 8290:p62 sample # 2) was prepared. A solution of 0.05mL SnBr_4 in 1g 5,6-bis(chloromethyl)-2-norbornene + 40mg polyENB (8290:p62, sample #2) was prepared. The solutions were placed in A+B sides respectively of an in-house manufactured 1mL cartridge fashioned from 2 1mL syringes ~~or~~ syringes (plastic/disposable) + a mixing chamber from the tip of a polypropylene pipette.



The mixing chamber was attached to the syringes with hot melt polyethylene adhesive.

To Page No. _____

Witnessed & Understood by me,

Brian Canelas

Date

Invent'd by

Peter Knoll

Date

Recorded by


Peter Knoll

From Page N ____

The cartridge was used to deliver the adhesive to 6 sanded (w/ 100 grit paper) polypropylene coupons over a 1in^2 area. The polypropylene coupons were mated with 6 additional sanded polypropylene coupons. The joints were held in place with a 170g weight.

After 24h, 3 samples were tested. Two pulled apart by hand + a third was pulled apart on the Speedy tester with a stress at break of 57psi.

After 72h, the 3 remaining samples were tested. Two pulled apart by hand + the third was pulled apart on the speedy tester with a stress at break of 217psi. The samples that pulled apart by hand were not fully cured.



To Pag No. ____


Witnessed & Understood by me,

Dat

Inv nted by

Jonathan Kendall

Dat



R corded by



From Pag No.

Bonding of Polypropylene Samples Using
EMIB + low levels of Grubbs' catalyst.

A solution of 0.5 mg (0.6 μmol) Grubbs catalyst in 1g (8.3 mmol) 5-ethyldene-2-norbornene was prepared & quickly applied to one face of a 1" x 4" x 1/8" polypropylene substrate (sanded with 100 grit paper & washed with acetone) over a 1 in² area.

The coupons were mated with sanded polypropylene coupons such that a 1 in² except ~~of~~ ~~overlap~~ overlap resulted. The solution was viscous with in about 30 sec & the 5th coupon pair was joined after some viscosity had built up. The bonds were held in place with a 170g weight. Monomer : Catalyst ratio = 14000:1

Samples 8327-66-1, 2, 3, 4, 5.

The procedure ~~as~~ above was repeated with 5 additional coupon pairs with the exception that

T Pag N.

Witnessed & Understood by me,

Dorian Canelas

Date

~~[Redacted]~~

Invented by

Peter Knobell

Date

~~[Redacted]~~

Recorded by

Peter Knobell

From Page No.

0.25 mg (0.3 μmol) Grubbs catalyst was dissolved in 1 g (8.3 mmol) 5-ethylidene-2-methylhexane resulting in a monomer:catalyst ratio of 28000:1. As before, the last carbon (8327-66-10) was handled after some viscosity had built up. Samples prepared were numbered 8327-66-6, 7, 8, 9, 10.

~~SAMR K~~ Samples were pulled on the Instron
at 0.5 in/minute.

stress @ max load

66-1	11.8 psi
66-2	12.7 psi
66-3	9.2 psi
66-4	fell apart
66-5	8.9 psi
ave	10.6 psi
std.dev	1.9 psi

stress @ max load

66-6	30.2 psi
66-7	89.9 psi
66-8	63.6 psi
66-9	81.4 psi
66-10	196.8 psi
ave	92.4 psi
std.dev	62.7 psi

To Page No.

Witnessed & Understood by me,

Brian Canelas

Date

Inventoried by

Patrick Russell

Date

~~Patricia Russell~~

Recorded by

Patrick Russell

From Pag No.

The Effect of Applying ENOB (60% NBD) to a
two part formulation. (5 + 1.0ml glass beads)

CONDITIONS

ENOB	10.8g
NBD	25.2g
Europrene	6.35g
Cabosil	2.0g

PROCEDURE

ENOB, NBD + Europrene were weighed into a glass jar and placed on a shaker for thirty minutes. 2g of Cabosil was added and shake for 5 minutes.

This was Side A of the formulation. It was transferred to a 10:1 cartridge (The A-side).

330mg of Grubbs Catalyst was dissolved in 5g of Dichloromethane (CH_2Cl_2) which was evaporated under flow of Nitrogen after 1.8g of Worthpar 100 processing oil was added. This resulted in a purple paste which was transferred to the B-side of the cartridge.

A 4" static gun and mixing tip and static gun was used to dispense the formulation. (1ml glass beads)

OBSERVATION

Fast curing seem to be a problem and the paste was too foamy. Also the mixing tip seem to be too long. Decided to do 50:50 ENOB/NBD + reduce the mixing tip.

To Page No.

Written & Understood by me,

Date

Invented by

Date

Recorded by

From Page No. _____

Repeat study of EMB/NBD to a two part formulation. (50:50) 5ml glass beads

CONDITIONS

EMB	185
NBD	185
Europrene	6.35g
Cabosil	2g

PROCEDURES Same as 8363-64

RESULT 5ml


SAMPLE ID	LOAD (psi)
836364A-1	79.30
" - 2	114.50
" - 3	74.87
" - 4	98.24
" - 5	<u>113.90</u>

SAMPLE 10ml

SAMPLE ID	LOAD (psi)	SAMPLE ID	LOAD (psi)	SAMPLE ID	LOAD (psi)
836364B-1	100.9	836365A-1	103.6	" - 2	137.0
" - 2	96.2	" - 3	58.9	" - 3	89.4
" - 3	58.9	" - 4	113.9	" - 4	99.1
" - 4	113.9	" - 5	101.2	" - 5	99.7
" - 5	101.2		X 94		X 106
			± 21		± 18

OBSERVATIONS

All of the samples failed adhesively



To Page No. _____

Witnessed & Understood by me,




Date

Invented by

Date

Recorded by



From Page No. _____

The Effect of Grubbs Catalyst with Cyclopentene/
Cyclohexene in a two part Adhesive formulation on
Polypropylene Substrate. (10:1 Cartridge)

FORMULATIONS

A-Side	1A	2A
Norbornadiene	22.5g	22.5g
ENB	15.0g	15.0g
Blendex	7.5g	7.5g
Cab-O-Sil	1.0g	1.0g
Zospheres	4.0g	4.0g

B-Side

	1B	2B
Grubbs Catalyst	0.385g	0.385g
Cyclopentene	4.615g	—
Cyclohexene	—	3.765g
Cab-O-Sil	—	0.10g
Blendex	—	0.75g

PROCEDURES

A-Side formulation (1A+2A) were combined and mixed by hand in a plastic cup, but the blendex did not dissolve in the monomers (NBD/ENB). Eurofend was substituted for Blendex, which was weighed in a bottle with the monomers. It was placed on a roller overnight, the formulation was successfully done the following day. A total of 2.4g of Cab-O-Sil was used in the formulation.

The B-Sides were done separately.

OBSERVATIONS

The adhesive was found to be very fast cure, less than 15 seconds for 1B and less than 10 seconds for 2B. The 4" mixing tip had to be cut in half. We were able to get 6 samples for 1B and only 1 sample for 2B.

To Pag N .

Witnessed & Understood by me,

Shane McGillion

Date

~~10/10/01~~

Invent'd by

Recorded by Jonathan Taylor

Date

~~10/10/01~~

Proj ct N . 8374
B kN . RESULTS

Fr m Page No. _____

SAMPLE ID	LOAD (kN)	FAILURE MODE
8374IB-1	165.68	Coh/Adh
" - 2	299.84	
" - 3	230.16	
" - 4	268.36	
" - 5	243.84	(7.232) 70.45
" - 6	187.00	

SAMPLE ID	LOAD (kN)	FAILURE MODE
8374II2B-1	123.38	Coh/Adh
" - 2		
" - 3		
" - 4		
" - 5		

To Page No. _____

Witnessed & Understood by me,

Steve Miller

Dat

10/10/00

Inv nted by

Recorded by

Joseph Taylor

Date

10/10/00

From Page No. _____

Repeat of 8374-11 using $\frac{1}{10}$ the amount of Grubbs Catalyst on the B-Side. The A-Side stays the same.

B-SIDE FORMULATION

Grubbs Catalyst

	<u>1B</u>	<u>2B</u>
Grubbs Catalyst	35mg	35mg
Cyclopentene	0.385g	—
Cyclohexene	4.95g	—
Cab-O-Sil	—	0.20g
Europrene	—	0.8g

	<u>A-SIDE</u>
Same as 8374-11	—

PROCEDURES Same as 8374-11RESULT

<u>SAMPLE ID</u>	<u>LOAD (PSI)</u>	<u>FAILURE MODE</u>
------------------	-------------------	---------------------

8374.151B-1 —

" - 2	4.20	Adhesive
" - 3	9.90	
" - 4	7.90	
" - 5	5.46	
	$\bar{x} 7$	
	$\sigma 2$	

<u>SAMPLE ID</u>	<u>LOAD (PSI)</u>	<u>FAILURE MODE</u>
------------------	-------------------	---------------------

8374.152B-1 —

" - 2	10.82	Adhesive
" - 3	6.20	
" - 4	5.18	
" - 5	4.98	
	$\bar{x} 7$	
	$\sigma 2$	

To Page No. _____

Witnessed & Understood by me,

Date

Invented by

Date

Recorded by

From Page No. _____

The Effect of Grubbs Catalyst with Cyclopentene, Cyclohexene in a two part Adhesive formulation on polypropylene Substrate.

FORMULATIONNorbornadieneTM

<u>A - SIDE</u>	<u>AMOUNT</u>	<u>ACT AMOUNT (x10)</u>
① Norbornadiene	22.5g	225g
② ENB	15.00g	150g
③ Europrene	7.5g	75g + 25g
④ Cab-o-sil	1.0g	10g
⑤ Zeospheres	4.0g	40g

B - SIDE

<u>1B</u>	<u>1B</u>	<u>2B</u>	<u>1B</u>
Grubbs Catalyst	75mg	75mg	75mg
Cyclopentene	4.616g	—	2.308g
Cyclohexene	—	3.765g	2.308g
Cab-o-sil	—	0.10g	0.10g
Europrene	—	0.75g	—

PROCEDURES Same as 8374-11

OBSERVATION

Grubbs Catalyst and Cyclopentene Cured in ~ 2 min resulting in a hard material. 50:50 Cyclopentene / Cyclohexene used instead.

T Pag No. _____

Witnessed & Understood by me,

Date

Entered by

Date

Shane Mill

Recorded by

Jonathan Taylor

From Page No. _____

SAMPLE ID	LOAD (PSI)	FAILURE MODE
8374221B1	12.42	Adh / Coh
" - 2	6.64	
" - 3	10.82	
" - 4	12.62	
" - 5	-	
	$\bar{x} 11$	
	$\sigma 2$	

SAMPLE ID	LOAD (PSI)	FAILURE MODE
8374222B-1	19.60	Adh / Coh
" - 2	5.20	
" - 3	11.62	
" - 4	9.10	
" - 5	-	
	$\bar{x} 11$	
	$\sigma 5$	

To Page No. _____

Witnessed & Understood by me,

Date

Inv. nt d by

Date

Recorded by

From Page No. 8374

The Effect of Grubbs Catalyst with Cyclohexene in
a two part adhesive formulation on polypropylene substrate.

A-Side

Used 8374-22 (Masterbatch)

B-SIDE

Componen ^t	Amount
Grubbs Catalyst	200 mg
Cyclohexene	3.765 g
Cabo-sil	0.20 g
Europrene	0.75 g

PROCEDURE

The Cyclohexene and Europrene were weighed into a small vial and placed on the paint shaker for 30 minutes. The mixture was added to the Grubbs catalyst in a plastic cup, the Cabo-sil was added next and mixed well by hand before transferring to the cartridge. Five samples were made and cured overnight in the hood.

RESULT

SAMPLE ID	TIME	16hr LOAD (psi)	FAILURE MODE
837451-1	"	101.86	Adh
" - 2	"	56.64	"
" - 3	"	141.98	"
" - 4	"	180.00	"
" - 5	"	312.60	Adh / Cob
		X 159	
		σ 87	

To Page No. 8374

Witnessed & Understood by me,

Shane Miller

Date

~~10/10/04~~

Inventied by

Recorded by

Date

~~10/10/04~~

Joseph Taylor

From Page No. _____

SAMPLE ID	TIME	LOAD (psi)	FAILURE MODE
837451B-1	15 min	163.52	Adh
" - 2	"	152.52	"
" - 3	"	160.24	"
" - 4	"	220.04	"
" - 5	"	169.58	"
		$\bar{x} \ 173$	
		$\sigma \ 24$	

SAMPLE ID	TIME	LOAD (psi)	FAILURE MODE
837451C-1	30 min	193.08	Adh
" - 2	"	206.36	"
" - 3	"	212.22	"
" - 4	"	212.58	"
" - 5	"		
		$\bar{x} \ 207$	
		$\sigma \ 9$	

SAMPLE ID	TIME	LOAD (psi)	FAILURE MODE
837467D-1	1hr	230.84	Adh
" - 2	"	232.62	"
" - 3	"	257.92	"
" - 4	"	278.76	"
" - 5	"		
		$\bar{x} \ 250$	
		$\sigma \ 20$	

SAMPLE ID	TIME	LOAD (psi)	FAILURE MODE
837451E-1	2hr	197.52	Adh
" - 2	"	212.92	"
" - 3	"	238.80	"
" - 4	"	202.46	"
" - 5	"		
		$\bar{x} \ 214$	
		$\sigma \ 15$	

To Page No. _____

Witnessed & Understood by me,

Date

Invented by

Recorded by

Date

From Page No. 8374

The Effect of Grubbs Catalyst with Cyclohexene in a two part adhesive formulation on polypropylene substrate.

A - SIDE

Compound	Amount
Cyclo Methacrylate	18.24g
Europrene	4.56g
mono-2(Methacryloyloxy)ethyl succinate	1.45g

B - SIDE

Compound	Amount
Grubbs Catalyst	200 mg
NaEtoBET ₃	1.29g (used 1.25g)
Ca-bo-sil	0.20g
Cyclohexene	3.76g
Europrene	0.50g

PROCEDURE

The Components were added together separately in a small plastic cup, hand mixed for ~ 2-5 minutes and then transferred to the cartridge. The Europrene and monomer were ^{weighted} placed into a small vial and placed on one point. Shaken for 30 minutes. A stir stick and a 16" mixing tip was used to dispense the adhesive on to polypropylene samples.

OBSERVATIONS

The samples were left to cure overnight - as they were still not cured after 2 hrs. They were pulled on the speeds faster after allowing to sit for 1 week.

RESULT Next pageTo Page No. 54

Witnessed & Understood by me,

Stan M.

Date

Invented by

Recorded by

Date

From Page No. _____

RESULTSAMPLE IDLOAD (PSI)FAILURE MODE

837453-1	95.32	Coh
" - 2	117.10	
" - 3	118.20	
" - 4	148.46	
" - 5	90.90	
" - 6	139.44	
" - 7	141.48	
" - 8	149.30	
" - 9	146.98	
" - 10	153.98	
" - 11	154.26	
" - 12	157.98	
" - 13	133.08	
" - 14	168.00	
" - 15	177.44	
" - 16	146.14	
" - 17	153.58	
" - 18	142.82	
" - 19	141.24	
X	140	
O	23	

To Page No. _____

Witnessed & Understood by me,

Date

Invented by

Date

Recorded by

From Pag No.

7-14-00

The effect of Grubbs Catalyst with Cyclohexene in a two part adhesive formulation on polypropylene Substrate.

A - SIDE

Used 8374-22 (masterbatch)

B - SIDE

Compound	Amount
Grubbs Catalyst	200 mg
Cyclohexene	3.765 g
Ca-bo-sil	0.20 g
Europrene	0.75 g

PROCEDURE

Same as in 8374-51

RESULT

SAMPLE ID	TIME	LOAD (psi)	FAILURE MODE
837455A-1	5min	277.62	Adh / Coh
" - 2		304.52	"
" - 3		264.64	"
" - 4		382.14	"
" - 5		297.40	"
		X 325	
		5	

} samples were pulled
between 5 - 10 minutes

SAMPLE ID	TIME	LOAD (psi)	FAILURE MODE
837455B-1	10 min	147.90	Adh
" - 2		198.68	"
" - 3		492.56	Coh
" - 4		225.66	Adh
" - 5		270.40	"
		X 279	
		5 120	

To Pag No.

Witnessed & Understood by me,

Shane M.

Date

Invented by

Recorded by

Date

Project N _____
B'k No. 8374 TITLE _____

56

From Page N _____

Repeated 837450 at 5 minutes.

Sample ID	Time(s)	Load (psi)	Failure mode
837450 C - 1	5 min	112.3	Adh
.. - 2	..	315.2	Adh/Coh
.. - 3	..	113.4	Adh
.. - 4	..	151.2	..
.. - 5	..	362.1	Adh/Coh
		X 2.11	
		0 106	

Jayon

[Signature]

To Page No. _____

Witnessed & Understood by me,

[Signature]

Date

[Signature]

Invented by

Date

[Signature]

Recorded by

[Signature]

From Page No. 100The effect of Grubbs Catalyst with Cyclopentene.A-SIDP

Used 8374-22 (Masterbatch)

B-SIDP

Compound

AMOUNT

A B

Grubbs Catalyst	200 mg	140 mg
Cyclopentene	4.8 g	4.86 g

PROCEDURE

Same as in 8374-51

RESULT

SAMPLE ID	Time	LOAD(g)	FAILURE MODE
837459A-1	1 hr	81.50	Adh
" - 2	"	79.50	"
" - 3	"	98.34	"
" - 4	"	120.54	"
" - 5	"	63.66	"
\bar{x} 89			
s 19			

Samples were pulled at 1 hr-1'15

SAMPLE ID	Time	LOAD(g)	FAILURE MODE
837459B-1	1 hr	13.00	Adh
" - 2	"	18.20	"
" - 3	"	73.62	"
" - 4	"	72.14	"
" - 5	"	38.92	"
\bar{x} 43			
s 26			

To Page No. 100

Witnessed & Understood by me,

Shane W.

Date

10/10/02

Invented by

R. c. r d e b y

Jonathan Taylor

Date

10/10/02

From Page N

The Effect of Grubbs Catalyst with Cyclohexene on
B-Side and ENB on A-Side.

FORMULATIONS

A-SIDE

Compound	Amount
ENB	37.5g
Europrene	7.5g
Zeeospheres	4.0g
Ca-bo-si	1.0g

B-SIDE

Compound	Amount
Grubbs Catalyst	200mg
Cyclohexene	3.765g
Ca-bo-si	0.2g
Europrene	0.75g

A-Side formulation was prepared by adding the ENB and Europrene together in a 4oz glass jar and placed on the paint shaker; then the fillers were added.
The same was done on the B-Side.

RESULT

SAMPLE ID	TIME	LOSS(%)	FAILURE MODE
8374/00-1	14:41:15m	81.08	Adh
" - 2	"	57.04	"
" - 3	"	82.54	"
" - 4	"	87.10	"
" - 5	"	53.52	"
		X 72	
		5 14	

J. Janice



To Page No.

Witnessed & Understood by me,

Date

Invented by

Date




Recorded by




From Page No.

The Effect of Super Grubbs Catalyst with Cyclohexene in a two part adhesive formulation on polypropylene substrate.

A-Side
used Comp Masterbatch 8374-22

Compound	AMOUNT	B-Side's
Super	8374-89A	8374-89B
Grubbs Catalyst	100 mg	50 mg
Cyclohexene	3.75 g	3.8 g
Ca-bro-Sil	0.20g	0.20g

* AII = 11, 20, & 30 minutes study

PROCEDURES

Both B-Sides were mixed separately by hand in a small plastic beaker and then transferred to the cartridge. Five samples were made for each set. They were allowed to cure over the week end.

Fine study was done with 8374-89A.

Type 1
Result $\frac{t_{\text{fail}}}{t_{\text{test}}} \times 100$ (%)

Sample ID	II Load (psi)	Failure Mode	Comment
837489AII 1	" 16.20	Adh	
" AII 2	" 392.14	Coh	Completely Cured in 15 min
" - 3	" 466.66	Adh/Coh	"
" - 4	" 11.80	Adh	"
" - 5	" 12.82	"	"
$\bar{x} 180$			
$\sigma 205$			

J. Gaynor
8374

To Page No. _____

Witnessed & Understood by me,

Date

Invented by

Date

Recorded by

From Pag No.—

SAMPLE ID	TIME	LOAD (psi)	FAILURE MODE	COMMENT
837489A-1	30min	15.74	Adh	
" AII-2	"	11.92	"	
" - 3	"	446.24	Adh/Coh	Completely Cured in < 5 min
" - 4	"	454.40	"	"
" - 5	"	474.24	"	"

SAMPLE ID	TIME	LOAD (psi)	FAILURE MODE	COMMENT
837489AII-1	30min	385.96	Adh/Coh	Completely Cured in < 5 min
" - 2	"	465.88	"	"
" - 3	"	465.10	"	"
" - 4	"	402.02	"	"
" - 5	"	X 432		
		σ 31		

SAMPLE ID	TIME(hr)	LOAD (psi)	FAILURE MODE	COMMENT
837489A-1	48+	43.38	Adh	
" - 2	"	54.86	"	
" - 3	"	229.62	Coh/Adh	Completely Cured in < 5 min
" - 4	"	41.40	Adh	
" - 5	"	42.70	"	
		X 82		
		σ 74		

SAMPLE ID	TIME(hr)	LOAD (psi)	FAILURE	COMMENT
837489B-1	48+	—	—	
" - 2	"	18.26	Adh	
" - 3	"	35.92	"	
" - 4	"	28.02	"	
" - 5	"	46.68	"	
		X 32		
		σ 10		

To Page N .

Witnessed & Understood by me,

Shane M

Date

Invent'd by

Recorded by

Gina Mae Taylor

Date